

Mobile NVSS Client Instruction

Live Stream

- Support 4/9/16 split preview
- Support screenshot
- Support PTZ control
- Double click preview with single split
- Slid interface to switch the camera to preview



Remote Playback

- Support to choose the date and time to playback
- Support to backup video to phone
- Support screenshot
- Support to play by frame and pause display



File Playback

- Support to play the video backup from remote playback
- Support screenshot
- Support to play by frame and pause display



DO Control

- Support to manage / control the DO of NVSS / Hybrid NDVR by your choice



Alarm Management

- Support to choose the device you want to get alarm information
- Support to choose the type of alarm information you want to get from camera and storage server



Log Search

- Support to choose device to get log information
- Support to set date and time to search log
- There are 5 kind of alarm type to filter the log information



General

- Support up to 16 channels live preview, PTZ control
- Support remote playback and backup record to phone
- Support connecting to our NVSS directly by P2P or custom
- Support swiping screen to switch cameras to preview
- Support to manage / control the DO alarm push function

Storage

- Support to backup video to phone from remote playback
- Support to capture picture and save to phone

<p>Remote Playback</p> <p>Playback with 1 split Support to choose date and time you want to playback</p>	<p>PTZ Function</p> <p>Control PTZ or speed demo through network Support to call a preset you have set</p>
<p>Alarm Function</p> <p>Push alarm information real time. Support to choose device and alarm you want to get information Send message from software to your phone.</p>	<p>Network Function</p> <p>Support to connect device with TCP/ P2P</p>